

Assembling the Battery Charge Sleeve Kit

Attach Retention Mechanism

1. Use Phillips screw to connect metal ring of coiled tether to battery charge sleeve.



2. Peel backing from metal plate on coiled tether and affix metal plate to back of 2020 base.

Note: For best adhesion allow 24 hour cure time before placing stress on metal plate.



Remove Battery from Imager

Remove end cap of imager (with a screwdriver or turn the thumbwheel).



Insert Battery into Charge Sleeve

1. Place squared-off end of battery into sleeve and slide it until it stops. Battery contacts should be showing through the small rectangular opening in the battery sleeve.
2. Press other end of battery until you feel a click.



Charge Battery

With battery inside battery charge sleeve, place battery charge sleeve into 2020 base with the battery contacts going in first and facing up.

