

# CK70|CK71

## Tethered Stylus Replacement Kit Instructions

指示笔更换配件说明

指示筆更換工具說明

Instructions du kit de remplacement du stylet à cordon

Anweisungen für den Ersatzteilsatz Stift mit Schnur

繋がれたスタイラスの交換キット使用説明書


테더 스타일러스 교체 키트 지침

Instruções para kit de reposição da caneta stylus presa

Инструкции по замене привязного пишущего элемента

Instrucciones para juego de repuesto del puntero con cordel

คู่มือการใช้ชุดเปลี่ยนปากกาสไตลัส





Worldwide Headquarters  
6001 36th Avenue West  
Everett, Washington 98203  
U.S.A.

tel 425.348.2600

fax 425.355.9551

[www.intermec.com](http://www.intermec.com)

© 2011 Intermec Technologies  
Corporation. All rights reserved.



## CK70/CK71 Tethered Stylus Replacement Kit Instructions



P/N 943-273-002