

Handstrap Instructions



The handstrap (P/N 825-196-xxx) provides you with a convenient way to carry your PW50 printer. The handstrap kit contains these items:

- Handstrap accessory
- These instructions


To attach the handstrap

1 Release the strap from the adjuster, and remove the strap from the VELCRO pad.




Note: VELCRO is a trademark of Velcro Industries B.V.


2 Insert the strap through the PW50 and VELCRO pad. Make sure the D-ring and adjuster are oriented as shown at the top of the PW50.



3 Place the strap on the VELCRO pad, and route the strap through the adjuster and D-ring as shown.



4 Close the VELCRO pad over the strap. You are now ready to use the printer with the handstrap.



5 (Optional) Install another handstrap on the other side of the PW50.





P/N 943-159-001



Worldwide Headquarters 6001 36th Avenue West Everett, Washington 98203 U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2008 Intermec Technologies Corporation. All rights reserved.