

MC3000 Series




Quick Start Guide

FEATURES


<http://www.zebra.com/mc3000>

See User Guide for more information
This guide is applicable to all MC30XX series products


POST IN WORK AREA




Battery Installation




MC3000S Back View




MC3000R Back View




ACCESSORY INSTALLATION



Comm/Charge Cables



Extended Life Battery



Extended Life Battery Strap/Door Assembly


CHARGING INSTRUCTIONS

⦿ = LED Indicator Location


Slow Flash = Normal Charge

Solid Amber = Full Charge


Fast Flash = Charging Error



Four Slot Spare Battery Charger





Single Slot Serial/USB Cradle




Four Slot Cradles
Charge-Only Cradle and Ethernet Cradle


OPTIMUM IMAGING AND SCANNING POSITIONS



MC3000S Scanning




MC3000R Scanning




OPTIMUM UPRIGHT BODY POSTURES

MC3000S





MC3000R



MC3000R




Avoid Extreme Wrist Angles



OPTIMUM BODY POSTURE

Optimum Body Posture for Low Scanning

Alternate left and right knees



Alternate left and right hand

Optimum Body Posture for High Scanning



Use a ladder

Taking breaks and task rotation recommended

Local Contact: _____

ZEBRA
 Zebra Technologies Corporation
 Lincolnshire, IL U.S.A.
 Zebra and the Zebra head graphic are registered trademarks of ZIH Corp. The Symbol logo is a registered trademark of Symbol Technologies, Inc., a Zebra Technologies company.
 © 2015 Symbol Technologies, Inc.
 72-68902-04 Rev A March 2015