




MC3190G

Quick Start Guide

<http://www.zebra.com/mc3100>
See User Guide for more information


FEATURES

MC3190G




POST IN WORK AREA


Comm/Charge Cables




Rubber Boot



Stylus Removal




BATTERY REMOVAL/INSTALLATION




CHARGING INSTRUCTIONS


LED Indicators: Slow Flash = Normal Charge | Solid Amber = Full Charge | Fast Flash = Charging Error



Four Slot Spare Battery Charger





Single Slot Serial Cradle



Four Slot Cradles

Charge-Only Cradle and Ethernet Cradle

HEADSET CONNECTION




ALTERNATE LEFT AND RIGHT HANDS
TAKING BREAKS AND TASK ROTATION RECOMMENDED

OPTIMUM SCANNING POSITIONS

OPTIMUM UPRIGHT BODY POSTURES



Avoid Extreme Wrist Angles





OPTIMUM BODY POSTURE

Optimum Body Posture for Low Scanning



Alternate left and right knees



Alternatete left and right hand

Optimum Body Posture for High Scanning



Use a ladder

Taking breaks and task rotation recommended

POST IN WORK AREA



Zebra Technologies Corporation
Lincolnshire, IL U.S.A.
Zebra and the Zebra head graphic are registered trademarks of the ZIH Corp. The Symbol logo is a registered trademark of Symbol Technologies, Inc., a Zebra Technologies company.
© 2014 Symbol Technologies, Inc.



72-124276-04 Rev A December 2014



<http://www.zebra.com/mc3100>

Local Contact: _____