



# Cleaning and Disinfecting Zebra TC51-HC Mobile Computers

The Zebra TC51-HC mobile computer is hard at work in healthcare facilities around the world. The fully-featured pocket sized device helps improve patient safety, the patient experience and staff productivity.

Just as with other devices that come into contact with patients, surfaces and healthcare workers, the TC51-HC should be cleaned after use with every patient and disinfected at regular intervals to reduce the risks associated with the spread of healthcare associated infections (HAIs) and microorganisms. The TC51-HC is specifically designed and built for the rigors of healthcare environments and can withstand repeated cleaning and disinfecting practices. It is important to use approved cleaning and disinfectant products to ensure that HAIs and microorganisms are removed and that the device is protected.

## **Approved Disinfectant Products for Zebra TC51-HC**

Clorox - Dispatch with Bleach

Clorox Healthcare Bleach Germicidal Wipes

Diversey- Dimension 256 Neutral Disinfectant Cleaner

Diversey - Virex II 256

Metrex - CaviWipes

Metrex - CaviWipes 1

PDI Easy Screen

PDI Sani-Cloth AF3

PDI Sani-Cloth Bleach

PDI Sani Cloth Plus

PDI Sani-Hands

PDI Super Sani Cloth Germicidal Wipes

The Clorox Company - 409 Glass and Surface Cleaner

Sani Professional Sani-Wipes

SC Johnson - Windex Original Glass Cleaner

Steris - Coverage Plus Germicidal Surface Wipes

Purell

#### Non-Approved Disinfectant Products for Zebra TC51-HC

The use of Non-Approved agents has potential to damage the product and should be avoided.

# Non-Approved Disinfectant Products for Zebra TC51-HC

Diversey -Oxiver Tb Wipes

Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes

For hospitals to protect patients and staff, it is critical to put a robust infrastructure of infection protection practices in place that includes the cleaning and disinfection of all mobile devices used by healthcare workers.

## THE TC51-HC — BETTER CONNECTIONS. BETTER CARE.

For more information, visit www.zebra.com/tc51hc or access our global contact directory at www.zebra.com/contact

