



Contents of the box:




1 Choose a plug for the universal power adaptor. The adaptor may already be fitted with the plug you need. If not:

1. Press the button on the power adaptor to release the plug.




2. Slide the existing plug out of the adaptor.




3. Slide the desired plug into the adaptor, until it clicks.

2 Connect the Docking Station to external power.




3 Insert the WORKABOUT PRO into the Docking Station.



Slide the WORKABOUT PRO into the Docking Station, then press the WORKABOUT PRO down until it latches.


Note: To release the WORKABOUT PRO, press the release button down, then pull the WORKABOUT PRO up.

4 Allow the WORKABOUT PRO to charge for 6 hours.




Note: Full battery performance is only reached after the first few full charge/discharge cycles.

5 If you have a spare battery, insert it into the Docking Station to charge it.




Over →

The behaviour of the charging indicator:



Behaviour	Charge Status
Off	No battery in charge well or in WORKABOUT PRO, or no external power
Solid green	Battery fully charged
Fast flashing green	Battery charged to less than 80% capacity
Slow flashing green	Battery charged to more than 80% capacity
Solid red	Battery temperature outside charge range
Flashing red	Battery not charging; battery fault

6 Connect the Docking Station to the host computer.



7 Install ActiveSync®.

Download ActiveSync® 4.0 or higher from <http://www.microsoft.com> and follow the instructions to install it onto the host computer.

8 Configure ActiveSync.

Follow the onscreen instructions provided by ActiveSync to establish a connection between the host computer and the WORKABOUT PRO in the Docking Station.




8100125
Rev. A

WORKABOUT PRO

Desktop Docking Station
WA4003-G2

Quick Start Guide

February 20, 2007 PN: 8100125.A



ISO 9001 Certified
Quality Management System

